


3020

3024




PARTS (NOT TO SCALE)












Complete the assembly with the upper horizontal sections to make it easier to fit the internal horizontal support poles.











Modulate Straight Frames

Modulate 3020 and 3024 (Straight)



April 2024



x1



TURN




Turn clockwise to lock foot in position
Turn anti-clockwise to unlock foot

NOTE: TWO POSITIONS FOR THE FEET (SEE OPTION 1 FOR SECOND POSITION)

NOTE: Sticker on base of foot shows the directions for locking/unlocking foot




8




NOTE: Adjustable feet can be used to level frame

OPTIONAL (EXTENSION KIT)

NOTE: EXTENSION SECTION SUPPLIED WITH 3824 FRAME




2




OPTIONAL (HALF FEET)

OPTION 1 NOTE: HALF FEET CAN BE POSITIONED ONTO THE FRAME TWO DIFFERENT WAYS




1



2



3




Turn clockwise to lock foot in position
Turn anti-clockwise to unlock foot




OPTION 2




1



2



3





Turn clockwise to lock foot in position
Turn anti-clockwise to unlock foot



CONNECTING MULTIPLE FRAMES

NOTE: SECOND FRAME (820 STRAIGHT NOT INCLUDED)



Remove one foot from second frame and align both frames on one foot

NOTE: FOLLOW OPTION 1 FOR HALF FEET TO CONNECT TWO FRAMES ON ONE FOOT

3024 (With Extension) Straight Frame and 820 Straight Frame